FECHNICA

ISO/TS16949 REGISTERED TB-059 • August 2015

How do I identify if I have an **Ultra LT Fifth Wheel?**

Method 1: Identify the Model Number

Model number location



Method 2: Provide the serial number to Fontaine Fifth Wheel at 800-874-9780 and someone will be able to tell you if you have an Ultra LT Fifth Wheel.

Location of 9 Digit Serial Number



Serial number engraved directly into the right side of fifth wheel skirt. Note: position 5 and 6 of the serial number indicates the year built. Serial number is always 9 digits.

If the model number identified using method 1 is on this list, you have an Ultra LT Fifth Wheel.

Ultra LT Model Numbers

AA4LWO675012

AA4LWO775012

AA4LWO875012

AATPL4000

SL4APB6250

SL4APB7250

SL4APB8250

SL4LWI675012

SL4LWI775024

SL4LWO675012

SL4LWO675016

SL4LWO675024

SL4LWO675036

SL4LWO775012

SL4LWO775016

SL4LW0775024

SL4LWO775036

SL4LWO875012

SL4LWO875016

SL4LWO875024

SL4LWO875036

SL4SMB6875

SL4SMB7875

SR4LWO675012

SLTPL4000

SRTPL4000

