

# Fontaine® Parts Advisory

Buy Fontaine Genuine Parts




**STOP**

Before you rebuild your fifth wheel, check to make sure the pull handle is straight!

**For Hard To Open or Excessive Slack on 6000/7000/7000CC Top Plates:**

- First check the pull handle for straightness
- If bent, replace immediately with KIT-PUL-6000L or R



[www.fifthwheel.com](http://www.fifthwheel.com)

800-874-9780

*If the pull handle is bent, the fifth wheel will have symptoms such as hard to open or excessive slack. Please look under the front of your NO-SLACK® fifth wheel where the pull handle hooks into the secondary lock (see red area in photo). If the pull handle is bent please replace it using Fontaine genuine parts: KIT-PUL-6000L or R.*



**FONTAINE®**  
PARTS CONNECTION

F o c u s e d   o n   F i f t h   W h e e l s

800-874-9780 • Fax 205-421-4400 • [www.fifthwheel.com](http://www.fifthwheel.com)